AMBULANCE PREVETATIVE MAINTENANCE SCHEDULES (Sample)

This is provided for your own use. The sample may be customized to meet local requirements.

Call Sign	Vehicle Number	Date (D M Y)	Work Order No.

Make / Model Year	Serial Number	Curr. Odom. Reading	M Km.
			☐ ☐

Ambulance Service Name	Last Service Date / Odometer Reading	Engine Hour Reading

NOTE: A INSPECTION INCLUDES 1-21 **C INSPECTION INCLUDES 1-37.**

A - Inspection Every 90 Days, 6,000 Km*.	N/A	Adjusted	Needs Attn	O.K.
1.) Change engine oil & filter.				
2.) Lubricate : front end & steering.				
3.) Lubricate : Brake cables, linkage, doors & hinges.				
4.) Check all fluid levels & top up as required.				
5.) Check for fluid leaks & report if found.				
6.) Check all steering components, pump, box, lines, tie rods etc.				
7.) Check suspension frame, springs & shocks.				
8.) Check exhaust system for leaks, mounting & condition.				
9.) Check transmission for leaks & secure mounting.				
10.) Check drive-line U joints, yokes, etc..				
11.) Check rear axle for leaks, oil level, & vent tube is clear.				

B INSPECTION INCLUDES 1-33

	N/A	Adjusted	Needs Attn	O.K.
12.) Check all hoses and clamps.				
13.) Check fuel system for leaks around tank & lines.				
14.) Check tire condition, & tread life. **(See Note# 1)**.				
15.) Check & adjust air pressures. **(See note# 2)**.				
16.) Drain water separator on diesel fuel filters.				
17.) Charge the conversion battery (deep cycle) & load test.				
18.) Clean battery terminals & ground cable ends, frame to box.				
19.) Inspect all belts and tensioners.				
20.) Check the operation of the lights, heater/ defrost, a/c, wipers/washers, & back-up alarm.				
21.) Road test & check, steering, brakes, and Drivability (Report any problems).				

B - Inspection / Semi-Annually, or every 18,000 Km*. (Includes all items in "A" above).				
22.) Pull wheels & inspect brakes.				
23.) Inspect friction material, caliper operation, rotors, drums, brake fluid lines, hoses & connectors.				
24.) Lubricate caliper slide rails and pins.				
25.) Rotate tires. **(See note# 6).**				
26.) Inspect wheel rims, studs, and locking nuts.				
27.) Pressure test cooling system.				

B - Inspection / Semi-Annually or every 18,000 Km*. (Includes all items in "A" above).				
28.) Check & record antifreeze rating. (- degrees)				
29.) Replace gas or diesel fuel filter.				
30.) Antifreeze Additive. **(See note# 3).**				
31.) Change Air Filter(s).				
32.) Front End Alignment (as required).				
33.) Wheel Balance (if required).				

C - Inspection / Annually or every 36,0000 Km's*. (Includes all items in "A" and "B" above).				
34.) Change spark plugs (if equipped).				
35.) Change transmission oil , filter and drain Torque Converter.				

C - Inspection / Annually or every 36,0000 Km's*. (Includes all items in "A" and "B" above).				
36.) Change differential fluid.				
37.) Repack front & rear wheel bearings.				

*** Inspections every 90 days, 6,000 Km's, or 125 Hours, which ever comes first.**

***REMINDER* Annual Inspection. (MOHLTC Vehicles require Safety Standard Certificate every Spring & Fall).**

NOTES:

1. **Minimum tread depth 4 mm.**
2. **Air pressure chart can be found on the drivers' door frame or in the TSU Bulletin.**
3. **Add 8-10 ounces of FW16 additive every 25,000 km's or on each Annual Inspection.**
4. **Change Coolant Starting from 80,000 km or at 36 months and subsequently every 50,000 km or 24 months thereafter. *Always use the original coolant. DO NOT MIX BLENDS!**
   *** No additives are required in the Gold coolant**
5. **Change Brake Fluid Every Year (DOT.4).**
6. **Retorque Wheel lug nuts to Fords Specifications. (See Owners Guide).**

ADDITIONAL COMMENTS / INSTRUCTIONS:

Service Provider Name:	Mechanic/Forepersons Signature: